

Sense Your City

Assemble Your Sensor Node









What's in the box:

- 1 Seeeduino Cloud
- 1 Grove Base-Shield
- 6 Grove Sensors:
 - 1 Digital Light Sensor
 - 1 Sound Sensor
 - 1 Temperature & Humidity
 - 1 Air Quality Sensor
 - 1 UV Sensor
 - 1 Dust Sensor
- 6 Jumper Cables
- 1 Weather Resistant Sensor Housing
- 1 Micro USB Cable



I. Sensor Assembly

1. Plug the Grove Base Shield into the Seeeduino. The black Grove base shield fits perfectly on top of the red Seeeduino. Do not too push too hard on the Grove base—even when it is plugged in completely there is some space between the two boards.

2. Find the switch on the Grove Base Shield and make sure it is switched to "5V." This indicates that we will be powering all sensors with five volts of electricity.

3. Plug a jumper cable into each of the Grove sensors. The cable only fits one way so don't force anything.

4. Once all the sensors are connected to cables, plug the other ends into the Grove Shield. Each sensor has a specific, labelled port that we will plug it into.



Sensor	Port
Digital Light Sensor	I2C
Sound Sensor	A0
Temperature & Humidity Sensor	D4
Air Quality Sensor	A1
UV Sensor	A2
Dust Sensor	D7

6. We have three different types of sensors. Some sensors are Analog, hence the "A" labeled ports. Analog sensors output a voltage between 0V and 5V, and we use that output to deduce the physical input to the sensor. Some sensors of our sensors are Digital, hence the "D" labelled ports. Digital sensors output data in 1's and 0's that computers, such as our Seeeduino, can easily understand. Finally, some sensors communicate over I2C, which allows bidirectional communication between the sensor and the computer.

7. Plug the micro USB cable into the Seeeduino. The small end of the Micro USB cable goes into the red Seeeduino. Later on, we will plug the other end into our computer to program our Seeeduino.

II. Install the sensor in the case

For this part, you might want to use some Velcro, 3M Dual Lock, or adhesive tape to keep your sensors in place. You don't *need* any of these supplies, but they will make your housing more secure and neat. For your reference, the top of the plastic housing has a tab with three small holes, the bottom of the housing has two large holes. This housing will protect our electronics from water and weather, but will also allow our sensors to measure the environment outside the case, through the two large holes on the bottom.

1. Put the Seeeduino inside of the box. The letters "A0...A1...A2....A3" on the black Grove Shield should be facing downwards towards the bottom of the case. Feed the micro USB cable through the left hole in the bottom of the case and plug it into the Seeeduino.

2. Using adhesive (tape, velcro, Dual Lock, etc), secure the Air Quality Sensor all the way on the left so it hovers just above the hole. Space is pretty limited in the case, so make sure the sensor is all the way to the left, the printed circuit board will be touching the plastic case.

3. Secure the Temperature and Humidity Sensor to the right of the Air Quality Sensor, in the middle of the case.

4. Secure the Dust Sensor on the right side of the case so it hovers over the bottom right hole. Make sure the metallic part of the Dust Sensor is pointing towards the top of the case.

5. Secure the Sound Sensor right above the Temperature and Humidity Sensor in the middle of the case. It should be facing upwards towards the top of the case (where the tab with three



holes is located). Take note of the small ridge that goes around the inside of the case, this is where the cover slides on. Make sure you leave enough clearance so you can slide the front cover of the case on. The white connector at the end of the jumper cable connected to the sound sensor should be below the ridge where the case slides on.

6. Feed the cables for the UV and Light sensors through the notches on the bottom of the case, and attach both sensors to the case so they are facing down. The circuit boards for these sensors are shaped so you can put them together like a puzzle. Connect the two sensors and attach them to the case.

7. Find the antenna—it's the green circuit board hanging freely from the Seeeduino. Run the antenna outside of the left hole on the bottom of the box, peel off the adhesive backing, and secure it to the case.

8. Once all of the sensors are in place, double check that all of the white connectors are securely plugged in. Slide on the front cover of the housing. If the case does not slide on easily, you will need to tidy up your wires. Make sure that the UV and Light sensors' jumper cables fit in the notches on the bottom of the housing. If the wires inside the housing are a mess, you can fold them and tape them together, or to parts of the case, so that they look neater and fit better. If possible, use several different colors of tape to do this, so that it will be easier to identify which wire is which incase you need to troubleshoot.

9. Use a wire tie, string, or tape to attach the USB cable to the middle tab at the top of the case. The sensor will should be able to hang vertically from the USB cable. We don't want it to turn upside down and expose the vulnerable sensors on the outside of the case to water or harsh weather. Make sure the USB cable is well secured between two of the three holes. For extra precaution, you can tape the Micro USB cable to the back of the sensor.



III. Program the sensor node

1. Before getting started, download the code resources at: https://github.com/Seeed-Studio/ DataCanvas/archive/master.zip

2. Go to : <u>http://localdata.github.io/data-canvas-signup/get-started</u> to register your sensor and acquire a private key from Localdata. Each sensor has its own unique Public ID and Private Key so that we can identify all unique data streams, we will also incorporate GPS coordinates, to plot all the sensors on a map.

3. Download and install the Arduino 1.5.8 IDE from <u>http://arduino.cc/en/Main/Software</u>. Windows has an easy installer. For Mac OS X, download the "Zip file for Java 6" version and drag the app to your applications folder. If you are prompted to install Java 6, follow the steps necessary to do so before continuing.



4. Plug your sensor node into a computer with the USB cable.

5. The Seeeduino Cloud needs two things: USB power (5V) and a wifi connection to the Internet. Make sure the Seeeduino is placed within range of your Wifi router (about 50 ft or so). The first time you plug in your Seeeduino, you will configure it to connect to your own Wifi network. If you change the location of your sensor, or your personal Wifi network settings, you will need to reset and reconfigure your Seeeduino.

6. After plugging in the Seeeduino, wait a moment and then check your wifi settings. Look for an available network nearby called something like "Seeeduino-XXXXXXXX" - that's your Seeeduino's private network, select it and connect to it.

10. Open a web browser and go to the following address: 192.168.240.1 - This is the default IP address of your Seeeduino, where you will always be able to find it (as long as you are on the same network). When prompted for a password enter "seeeduino" and click "Log In."

Yún ×		÷. =
		<i>a</i> =
Θ	Welcome to your Arduino Yún. Please enter password to access the web control panel	
ARDUINO	PASSWORD	
	Please be sure you have cookies enabled before proceeding.	
	LOG IN	

11. Give your board a catchy name, something that you will remember. Create a password that is at least eight characters. Select your Wifi network from the list of "Detected Wireless Networks," enter your Wifi network's password.

	For more advanced network configuration features, see the <u>advanced configuration panel (luci)</u>				
ARDUINO YÚN	YÚN BOARD CONFIGURATION YÚN NAME * Aethera PASSWORD CONFIRM PASSWORD				
	TIMEZONE * America/Los Angeles				
	CONFIGURE A WIRELESS NETWORK C DETECTED WIRELESS NETWORKS EAB1023 (WPA2) C Refresh				
	WIRELESS NAME * EAB1023 SECURITY WPA2 © PASSWORD * ••••••				
	DISCARD CONFIGURE & RESTART				

Note: If you ever move your Seeeduino to another wifi network, you will need to reset the Seeeduino's wifi processor. The reset button for WiFi is located on the top left corner of the Seeedunio, opposite the USB connector. When you press the button, the WLAN LED will flash. If you move to a different network and can no longer wirelessly access the Seeeduino through its web interface, you can reset the Seeeduino's network configuration by pressing the Wifi reset button for longer longer than 5 seconds, but less than 30, which will reboot the AR9331 wifi processor. The WiFi configuration will be reset and the Seeeduino will once again start its own Wifi network "Seeeduino-XXXXXXXXXXXXXXXX." Log on to the Seeeduino network, go to 192.168.240.1 in a browser, and configure the Seeeduino for the new network settings.

12. Click the "Configure and Restart" button. The Seeeduino will restart and connect to your personal wireless network.

● ● ● ● Yún ≅ × ● ← → C ☆ □ taurin.local/cgi-bin/luci/;stok=a2f56f0a0f831cecf1b0c6698ed3ee42/webpanel/config					
$\Theta \oplus \Theta$	CONFIGURATION SAVED!				
ARDUINO YÚN	I'm restarting. Please connect your computer to the wireless network called EAB1023 .				
	Restarted! You'll find me here.				
aethera.local					

13. Disconnect your computer from the "Seeeduino-XXXXXXXXXXXXXX" wireless network and connect your computer to your personal wireless network.

14. Once connected, direct your web browser to: <u>yourseeduinoscatchyname.local</u>. You should see the same Arduino interface as before, but this time on your own wireless network. You can also direct your browser to the Seeeduino's default IP address: 192.168.240.1.

15. Locate the code resources you downloaded in Step 1 and open the sense_your_city.ino. It should open within the Arduino IDE.



16. Add the libraries in your sense_your_city folder to your local Arduino Library. The easiest way to do this is to directly copy the two folders located in *sense_your_city/libraries* to your



Arduino's local library folder. On OS X the local Arduino library is located at /Users/

yourusername/Documents/Arduino/libraries.

The more common way to add libraries is to use the "Add Library..." function found in the "Sketch" menu in the Arduino IDE. Go to Sketch > Import Library... > Add Library...



16. Individually add both of the libraries located in the *sense_your_city* folder by selecting each folder individually and clicking "Choose." Go to Sketch > Import Library... > Add Library... to ensure that the libraries have been added successfully. You will also see message in the black console at the bottom of the Arduino IDE indicating success or that an error has occurred.

	Select a zip file	or a folder containing the library you'd like t	o add
		Digital_Light_Sensor	
der File Edit View Go Window Help			🔹 🔹 🤶 📾 Wed 12:34 AM ta
sense_your_city Arduino 1.5.8			
sense_your_city			
/*************************************	•••	libraries	
* Upload data to Localdata servers from Seeeduino Cloud.	< >		Q Search
* Part of the DataCanvas Project. More into at DataCanvas.org	All My Files	Arduino 🕨 🛅 libraries	Digital_Light_Sensor
<pre>* Development environment specifics: * IDE: Arduino >= 1.5.6-r2</pre>	Cloud Drive	Clarify Documents	Humidity_TSensor_pro
 Hardware Platform: Seeeduino Cloud 	AirDrop	Max 7	readme.txt
<pre>* This software is licensed under The MIT License (MIT) *</pre>	Applications	Native Instruments	
* Permission is hereby granted, free of charge, to any person obtain	Desktop		
 in the Software without restriction, including without limitation 	the Documents		
 to use, copy, modify, merge, publish, distribute, sublicense, and/ copies of the Software, and to permit persons to whom the Software furnished to do so, subject to the following conditions: 	or s a is Downloads		
* The above copyright notice and this permission notice shall be inc	Devices		
* all copies or substantial portions of the Software. *	Remote Disc		
* THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EX * IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTAGE	(PRES Shared		
* FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT * AUTHORS OF COPYOCALT HOLDERS BE LIABLE FOR ANY CLAIM DAMAGES OF CO * AUTHORS OF COPYOCALT HOLDERS BE LIABLE FOR ANY CLAIM DAMAGES OF C	SHAL taurindb		
* LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, AF	RISIN Tags		
* OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEAL * THE SOFTWARE.	part	Dangalore	•
		Singapore	
<pre>#include <process.h> // Process.h is used to construct Shell comm #include <avr pamspace.h=""></avr></process.h></pre>	mands and read the results.		
#include <dht.h></dht.h>			
<pre>#include <nire.n> #include <digital_light_tsl2561.h></digital_light_tsl2561.h></nire.n></pre>			
/* User Configuration */		ineiro	
#define USER_ID "ci3yvonmr000002xnvh5a116p" #define PRIVATE_KEY "0jIyZDljNGU3LTdjM2UtNDJmMv1iZTc3LTk5MGVh	ZGViNWIxZA=" //Also known d	as	•
#define LNGLAT "[37.7902370,-122.2300810]" // Get you	ur LONGITUDE, LATITUDE at http://	//m	
// Check your data> https://localdata-sensors.herokuapp.com/api/sc	ources/USER_ID_GOES_HERE/entries	s?s	• • • •
()4		

19. Confirm that the Arduino IDE is configured for your board. Go to Tools > Board > Arduino Yún.



20. Confirm the correct communication Port. Go to Tools > Port > /dev/tty.usbmodemXXXX (Arduino Yún). Now, your Arduino IDE is properly configured to program your Seeeduino.

É	Arduino	File	Edit	Sketch	Tools	Help			۽ 🕑
					Auto Archi	Format	жт	sense_your_city Arduino 1.5.8	
					Fix E	ncoding & I	Reload		ø
					Seria	I Monitor	ዕ <mark></mark> ೫M	city	
					Boar	d	•	***************************************	0
					Port		•	/dev/cu.Bluetooth-Incoming-Port	
					Progr Burn	rammer Bootloader	 IDE: A Hardwa This softw 	/dev/cu.Bluetooth-Modem /dev/cu.usbmodem1411 (Arduino Yún) /dev/tty.Bluetooth-Incoming-Port /dev/tty.Bluetooth-Modem /dev/tty.usbmodem1411 (Arduino Yún)	
			Ŵ		N.A		<pre>* Permission * of this so * in the Sof * to use, co</pre>	is hereby granted, free of charge, to any person obtaining a copy ftware and associated documentation files (the "Software"), to deal tware without restriction, including without limitation the rights py, modify, merge, publish, distribute, sublicense, and/or sell	

21. Make some necessary modifications to the sense_your_city.ino code. Insert the user ID and private key sent to you by Localdata in the space provided between the quotation marks at the tope of the code.

	9	Local Data Key — Edited		1	sense your city Arduino 1.5.8	
¶ ∽ Times ≎ Bold	0 12 V 🖿 💉 B					<mark>ب</mark> ور
0 I I I I 2	3	15 16 17 18	, , , , , , , , , , , , , , , , , , ,	sense_your_city §		
				* THE SOFTWARE.	*********	ŕ
id	token	encoded auth value		#include <process.h> //</process.h>	/ Process.h is used to construct Shell commands and read the results.	1
ci3yvonmr0200ds02xnvh5a1l6p	22d9c4e7-7c3e-42f3- be77-990eadeb5b1d	OjlyZDljNGU3LTdjM2UtNDJmMy1iZTc3LTk5MGVhZGVit	√WIxZA==	<pre>#include <avr pgmspace.h=""> #include <dht.h> #include <dht.h></dht.h></dht.h></avr></pre>		-
				<pre>#include <digital_light_ts< pre=""></digital_light_ts<></pre>	L2561.h>	
To confirm that data is arriving: https://localdata-sensors.her	okuapp.com/api/v1/sou	ccs/cl3yvonmr000002xnvh5all6p/entries?startIndex	=0&count=10	/* User Configuration */ #define USER_ID #define PRIVATE_KEY #define LNGLAT	"ci3yvonm=0200ds02xnvh5o116p" "oj1y2D1jHGU3LTdjHQUHQJmHy1iZTc3LTK5MGVhZGViNMTxZA…" //Also known "[LOMGTUDE_LATITUDE]" // Get your LONGTUDE, LATITUDE at <u>http://my</u> 0	as " (6000
				// Check your data> http://	ps://localdata-sensors.herokuapp.com/api/sources/USER_ID_GOES_HERE/entrie	s?st
San Frai	ncisco	Boston		/*Define sensor locations of #define pin_uv #define pin_sound #define pin_oir_quality #define pin_dht #define DHTTYPE	on Grave */ A2 // UV sensor A0 // Sound sensor 7 // Dust sensor (D7) 4 // Hr Quittys	
			Clown Costum	#define FP(string_literal) /* Define Data Sampling Fur float iReadTemperature(void float iReadHumidity(void); float iReadDensityDust(voi	<pre>(reinterpret_castsconstFlashStringHelper *>(string_literal)) nctions */ 0; 0;</pre>	

22. Calculate your sensor's GPS location by going to mygeoposition.com and entering the address where your sensor is installed. Click the "Calculate geodata" button. Click the "Copy (x,y)" button to copy your GPS coordinates and paste them into the Arduino IDE.



23. After pasting your coordinates, make sure to reverse them so **longitude is first and latitude is second**.

)		sense_your_city Arduin	o 1.5.8	
					P
sense_	your_city §				
********	- I WARE . ! * * * * * * * * * * * * * * * *		******	****/	Ô
#include < #include < #include < #include < #include <	<pre>cProcess.h> cavr/pgmspace.h cDHT.h> cWire.h> cDigital_Light_</pre>	// Process.	h is used to construct She	ll commands and r	read the results.
/* User Co #define US #define PF #define LN	onfiguration */ SER_ID RIVATE_KEY #GLAT	"ci3yvon "0jIyZDL "[-122.4	mr0200ds02xnvh5a1l6p" jNGU3LTdjM2UtNDJmMy1iZTc3L 185030,37.7543920]" //	Tk5MGVhZGViNWIxZ/ Get your LONGITUE	→ //Also known as "E DE, LATITUDE at <u>http://myg</u>
	MyGeoPosit	tion.com - Free	• × 🔘		
← → C	nt 🗋 myg	geoposition.	com		☆ 🛧 💭 🔳
	Geocoding	Latitude • Geo 26	Desition • Elevation • • • • • • • • • • • • • • • • • • •	Geotags • Geo N •CO ancis ×	o-Metatags
	Geocoding •	Geo 9 26 exac	65 Mission Street, San Francisty	Geotags • Geo Colored ancis × rodata	o-Metatags
About	Geocoding •	Ceodata	Congitude • Elevation • Congression Street, San Franciscus etly • Calculate ger Geo-Tags/-Metatags	Geotags • Geo Colored ancis × odata KML/GPX	Link this map
About	Map 21st St	Geodata	Active Calculate get Geo-Tags/-Metatags	Geotags - Geo Codata KML/GPX	Do-Metatags
About	Map 21st St	Geodata	Action Street, San Francisco Street, San Fra	Geotags - Geo Control Control	De-Metatags
About Gueneral R	Map 21st St Hill St	Geodata	Longitude • Elevation • OPOSICIO 65 Mission Street, San Fra ttly ¢ © Calculate ge Geo-Tags/-Metatags 2665 Mission Stree Latitude: 3 3	Geotags - Geo Colored ancis X rodata KML/GPX Vanguard Pr eet, San Francisco 7.7543920 7° 45' 15.81" N	Link this map
About Guenters R	Map 21st St Hill St	Latitude • Geodata	Longitude • Elevation • OPOSICIO 65 Mission Street, San Fra ttly ¢ © Calculate ge Geo-Tags/-Metatags 2665 Mission Stree Latitude: 3 3 Longitude: -1 Latin An	Geotags • Geo Codata KML/GPX Vanguard Pr eet, San Francisco 7.7543920 7° 45' 15.81" N 22.4185030 22° 25' 6.61" W	De-Metatags Link this map operties Map Satellite D, CA 94110, USA × Copy (x,y) Copy (x°,y°)
About Gueto St +	Map 21 st St Hill St	Geodata	Action of the second se	Geotags - Geo ancis × rodata KML/GPX Vanguard Pr eet, San Francisco 7.7543920 7° 45' 15.81" N 22.4185030 22° 25' 6.61" W 1.76 m	Link this map operties Map Satellite b, CA 94110, USA × Copy (x,y) Copy (x°,y°)

24. Click the check button at the top of the sense_your_city window to verify that the code modifications you made are OK. Next, click the play button to upload your code to the Seeeduino.



25. Go to Tools > Serial Monitor to open the serial monitor and make sure that everything is working.... If it is, you will see new window that contains incoming communication from the Seeeduino, including verification that you are uploading online - "Posting Data!"

Finder File Edit View Go Window	Help	🕑 🌲 📇 🖇 🐠 🛜 15899 Wed 12:47 AM taurindb
	(dau/thuushmasham1411 (Ashuina Viin)	sense_your_city Arduino 1.5.8
	/dev/tty.asbinodem1411 (Arduno 10)	
		sense_your_city
Posting Data! Sending command: curl -X POST -H "Authorizati Maximum sound level:430 Created Posting Data! Sending command: curl -X POST -H "Authorizati	on: Bearer OjIyZDljWGU3LTdjWZUENDJWMy11ZTc3LTK5MGVhZGVINNTxZA na: Bearer OjIyZDljWGU3LTdjWZUENDJWMy11ZTc3LTK5MGVhZGVINNTxZA	Sense Your City Upload data to Localdata servers from Seeeduino Cloud. Part of the DataCarwas Project. More info at DataCarwas.org Development environment specifics:
Maximum sound level:448 Created		IDE: Arduino >= 1.5.6-r2 Hardware Platform: Seeeduino Cloud *
Sending command: curl -X POST -H "Authorization	on: Bearer OjIyZDljNGU3LTdjM2UtNDJmMy1iZTc3LTk5MGVhZGViNWIxZA=="	* This software is licensed under The MIT License (MIT) *
Partinum sound tevel:430 Created		Permission is hereby grouted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:
		* The above copyright notice and this permission notice shall be included in * all copies or substantial portions of the Softamer. * The SoftWare IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR
		* IMPLIED, INCLUDING BUT NOT LIMITED TO THE MARRANTIES OF MERCHANTABILITY, FITNESS FOR FAMATCLUAR DURPOSES AND NONINFRUNCEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, METHER IN AM ACTION OF CONTACT, TORT OR ON DHERMISE, ARTISTING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.
✓ Autoscroll		<pre>finclude @Process.h> // Process.h is used to construct Shell commands and read the results. #include advf/gmspace.h> #include advfr.h> #include advfr.h> #include advire.h></pre>
		<pre>/* User Configuration */ #define USER_ID *cl3yvomm000002xrvh5all6p* #define USER_ID *0];XCl3jLCd;MCUHMDJAMyliZTc3LTk5MCVH2GVHMWIxZA* #define LNGLAT *0];XCl3jLCd;MCUHMDJAMyliZTc3LTk5MCVH2GVHMWIxZA* #define LNGLAT *[37.7902370,-122.2300818]* // Get your LONGTUDE, LATITUDE at http: </pre>
		// Check your data> https://localdata-sensors.herokuapp.com/api/sources/USER_ID_GOES_HERE/entri
		Done uploading.
		Maximum is 2,560 bytes.
		6 Arduino Yún on /dev/tty.usbmodem

26. Finally, check the Localdata site to verify that your code is uploading. In a web browser, go to the following address:

https://localdata-sensors.herokuapp.com/api/sources/YOUR_USER_ID_GOES_HERE/entries? startIndex=0&count=1000

Be sure to change YOUR_USER_ID_GOES_HERE to the user ID you received from Localdata. Press your browser's reload button several times over the course of several minutes to make sure data is uploading online. Data should be uploading about every 30 seconds or so. If everything is working, do a super funky victory dance!

O https://localdata-sensors.h ×	
🗲 -> C n 🔒 https://localdata-sensors.herokuapp.com/api/sources/ci3mv36vi0001ep0uyo5kcjbx/entries?startIndex=0&count=1000000	* ≡
[3/./3023/,-122.230001], airquairty : warmup , airquairty raw 131, dust 12/8.34, numinity 138.3, right 10, sound 13/2, temperature 184.02, uv 1238.01	111
<pre>("source:":climv3bv10001ep0uyo5kcjbx","timestamp":"2014-12-19T12:13:10.0002","data":{location": [37 700737 _122 230011 "sirvality":WarmIn" "sirvality ray":51 "dust":104 3 "humidity":34 3 "light":0 "gound":1548 "tampersturg":83 84 "hum":258 01</pre>	
[37.3025], 122.230001], argumatry : Maimory, argumatry_naw is, date ise.05, number 30.5, right to, Sound ise, competence is.ex, uv isseries (sound ise, competence is.ex, uv isseries), and iseries (sound iseries).	,,,
37.790237,-122.230081], "airquality": "WarmUp", "airquality_raw":51, "dust":194.03, "humidity":36.3, "light":0, "sound":1616, "temperature":83.84, "uv":258.01	}},
{"source":"ci3mv36vi0001ep0uyo5kcjbx","timestamp":"2014-12-19T12:13:30.000Z","data":{"location":	
[37.790237,-122.230081], "airquality": "WarmUp", "airquality raw":51, "dust":194.03, "humidity":36.3, "light":0, "sound":1564, "temperature":83.84, "uv":258.01 ("source": "ciaw:30001000000005kcibw": "timestemp":"2014.12_100"12_11340.0000" "deta="timestion".	}},
[37.790237,-122.23008], "arguality"; "Marmbly", "airquality raw":46,"dust":367.75, "humidity":36.3, "light":0, "sound":1808, "temperature":83.84, "uv":258.01	<pre>}},</pre>
{"source":"ci3mv36vi0001ep0uyo5kcjbx","timestamp":"2014-12-19T12:13:50.000Z","data":{"location":	
[37.790237,-122.230081], "airguality": "WarmUp", "airguality raw":56, "dust": 367.75, "humidity": 36.2, "light":0, "sound":1744, "temperature":83.84, "uv":258.01	}},
("source":"cl3mv36v10001ep0uyo5kcjbx","timestamp":"2014-12-19T12:14:00.0002","data":{location": [37 20027 _122 230011 "sirvality":Warmin" "sirvality ray":55 40ust":35 5 "busidity":35 3 "licht":14 "sound":1548 "temperature":33 44 "ur":258 0	111
("source": ciam36vi001ep0vo5kcibx", 'timestamp': 2014-12-21x17:06:53.0002", 'data": {"location":	-,,,
[37.790237,-122.230081], "airquality": "WarmUp", "airquality raw": 40, "dust":-1, "humidity": 27.3, "light": 5, "sound": 2728, "temperature": 80.24, "uv": 258.01}},	
{"source":"ci3mv36vi0001ep0uyo5kcjbx","timestamp":"2014-12-21T17:07:03.000Z","data":{"location":	
[37.790237,-122.230081],"airquality": "WarmUp","airquality_raw":38,"dust":392.5,"humidity":24.4,"light":5,"sound":3072,"temperature":81.5,"uv":253.14}	,
{ Source : clasmy Soview Deputyos Xcjpx , tamestamp : 2014-12-211710/116.0002 , data :{ location : [37.7007.120.230081: "airmailter", "airmailter raw":40. "dust":302.5 "humiditer".42.4 "light":5. "sound":2636 "temperature":81.32 "uv":253.141	۱.
("source": ci3my36vi0001ep0uvo5kcipx", timestamp": 2014-12-21T1:07:26.0002", 'data":{"location":	,,
[37.790237,-122.230081], "airquality": "WarmUp", "airquality raw": 44, "dust": 392.5, "humidity": 24.4, "light": 5, "sound": 2640, "temperature": 81.32, "uv": 258.01}	},
{"source":"ci3mv36vi0001ep0uyo5kcjbx","timestamp":"2014-12-21T17:07:36.0002","data":{"location":	
[37.790237,-122.230081], "airquality": "WarmUp", "airquality_raw":39, "dust":2799.46, "humidity":24.5, "light":6, "sound":2492, "temperature":81.32, "uv":258.0 ("source", "soiam:35% in 001 so humory "temperature":39, "dust":2799.46, "humidity":24.5, "light":6, "sound":2492, "temperature":81.32, "uv":258.0	1}},
(37.790237122.23081). "airguality": "WarmUp". "airguality ray":44.74 "dust":2799.46. "humidity":24.5. "light":5. "sound":2388."temperature":81.32."uv":253.1	4}}.
{"source":"ci3mv36vi0001ep0uyo5kcjbx","timestamp":"2014-12-21T17:07:57.0002","data":{"location":	-777
[37.790237,-122.230081],"airquality":"WarmUp","airquality_raw":44,"dust":2799.46,"humidity":24.5,"light":12,"sound":2268,"temperature":81.32,"uv":253.	14}}
/("source': "ci3mv36v10001ep0uyo5kcjbx", "timestamp": "2014-12-21T17:08:07.0002", "data": ("location":	
[3/./9023/,-122.230031], alrquality : warmup, alrquality_raw iso, qust :2200.38, numlaity :24.4, 11gnt :12, sound :2452, temperature :81.5, uv :258.0 // "course", colama; Kariona :	1}},
[37.790237,-122.230081],"airquality": "WarmUp", "airquality raw":44, 'dust": 2260.58, "humidity": 24.5, "light": 12, "sound": 2332, "temperature": 81.5, "uv": 253.1	4}},
{"source":"ci3mv36vi0001ep0uyo5kcjbx","timestamp":"2014-12-21T17:08:27.000Z","data":{"location":	
[37.790237,-122.230081], "airquality": "WarmUp", "airquality raw":41, "dust": 2260.58, "humidity": 24.4, "light": 12, "sound": 2700, "temperature": 81.5, "uv": 258.0	1}},
("Source": colamySylubulepUuyoSkojpx", timestamp:://otalicy.com/silubulepuyoskojpx", tamestamp://otalicy.com/silubulepuyoskojpx", timestamp://otalicy.com/silubulepuyoskojpx", timestamp://otalicy.com/silubulepuyoskojpx	111
("source":ciawa36vi001ep0wo5kcibx", timestamp"; 2014-12-21T17:08:47.000%", data"; {"location";	± <i>;;;</i> ,
[37.790237,-122.230081],"airquality": "WarmUp", "airquality_raw": 35, "dust": 571.34, "humidity": 24.2, "light": 12, "sound": 2452, "temperature": 81.5, "uv": 258.01	}},
{"source":"ci3mv36vi0001ep0uyo5kcjbx","timestamp":"2014-12-21T17:08:57.000Z","data":{"location":	
[37.790237,-122.230081], "airguality": "WarmUp", 'airguality raw": 35, 'dust": 571.34, 'humidity": 24.2, "light": 12, "sound": 2380, "temperature": 81.5, 'uv": 253.14	}},
{ Source : clsmv3sv10001ep0uyOoxc1px ; tlmestamp : 2014-12-21711/0950/.0002 ; data :{ loCatlon : [37.790237122.230611 _=aircnality := WarmIn"_=aircnality raw":404014: "	11.
<pre>("source": ci3mv36vi000lep0uyo5kcjbx", timestamp": 2014-12-21T17:09:17.0002", "data": { location":</pre>	
[37.790237,-122.230081],"airquality":"WarmUp","airquality_raw":39,"dust":257.53,"humidity":24,"light":12,"sound":2264,"temperature":81.5,"uv":253.14}}	,
{"source";"ci3mv36vi0001ep0uyo5kcjbx","timestamp":"2014-12-21T17:09:28.0002","data":{"location":	
[3/./9023/,-122.230081], "arguality: "WarmUp", "arguality:aw":39, dust :25/.33, humidity":24.1, "light":5, "sound":2456, "temperature":81.68, "uv":253.14	} } ,
[37.790237,-122.23008], arguality: WarmUp; arguality raw 139, dust 1257.53, humidity 124, "light": 5, "sound": 2480. "temperature": 81.5. "uv": 253.14}).	
{"source":"ci3mv36vi0001ep0uyo5kcjbx","timestamp":"2014-12-21T17:09:48.000Z","data":{"location":	
[37.790237,-122.230081],"airquality": "WarmUp", "airquality_raw":39,"dust":838.78, "humidity":24.2,"light":5,"sound":2324,"temperature":81.5,"uv":258.01}	},
("source":"cilmv36v1000lep0uyo5kcjbx","timestamp":"2014-12-21171.09:58.0002","data":("location": 127.20027_122.200011_"simulity:"Erzoph"_"simulity:"simulity	,
<pre>(3/./3023//12222530043), arguarry : fresh, arguarry_raw:s0, uust isso:/o, huminity 124.1, right is, sound 12356, temperature :81.08, uV :258.01} ("source": "ciama3640000e0/uuoSkcibx", "timestamp":2014-12-21T1710:08.0002", data":("location":</pre>	57
[37.790237,-122.230081], "airquality": "Fresh", "airquality_raw":44, "dust":838.78, "humidity":24.1, "light":5, "sound":2292, "temperature":81.5, "uv":258.01}}	1



IV. Node Installation

After we have confirmed that our sensor is successfully uploading data to the web, we are ready to install it outside. Place the sensor somewhere interesting - a busy street corner, near a public transit station, next to a public park, etc. Make sure the sensor is always safe from harsh weather conditions. If terrible weather is in the local forecast, it is probably a good idea to unplug or move your sensor somewhere safer. If you do decide to move your sensor, don't forget to reconfigure the wireless settings and make sure to update your new GPS coordinates in the sense_your_city.ino Arduino code.

1. Unplug the Seeeduino's USB cable from your computer and power the sensor from a power outlet. You can also use any standard USB port to supply your sensor with power, just make sure the Seeeduino is always powered and check on it from time to time. You can tell if the Seeeduino is powered by looking into the bottom holes of your housing. You should always see some LEDs blinking inside the case.



2. Install your sensor outside, hanging it from the USB cord. You may want to use a utility clip to secure the USB cord to a ledge, or perhaps the best way to hang your sensor is to secure the USB cord to an object *inside* your dwelling and hang the sensor out your window. At SEEED, the sensor hangs from an office window, the USB cable was secured and wrapped around a table leg inside. There are many ingenious methods to make sure that your node does not fall down to the ground and cause a tragic, tragic accident—choose one of them.

3. Once your sensor is installed, double check to make sure it is still uploading data online. Go to the URL in Step 25 to make sure data is still posting to the Localdata servers. If your sensor is not uploading data, it is probably too far away from your wifi router. Try moving the sensor closer to the wireless router. Unplug the USB cable from the power outlet to reset the Seeeduino.

If you have verified that your sensor is up and running, do a celebratory victory dance, make it extra funky. Congratulations, you are now ready to Sense Your City!

Follow along with the project at DataCanvas.org to see how artists, developers, and enthusiasts are turning this environmental data into meaningful media. Be a part of the conversation, ask questions, and post photos at https://www.facebook.com/groups/datacanvas/ and stay tuned!

Troubleshooting:

If you have any questions or run into roadblocks, check the FAQ at <u>http://datacanvas.org/sense-your-city/</u> You can also post questions in the Facebook group listed above.